

# **KNIGHT SERIES**



Effective September 2023 This guide supersedes all previous versions

3842 Redman Drive Fort Collins, CO 80524 MODEL COVERED: KL408A

1-800-797-7974 www.CommandLight.com

# THANK YOU


Please allow us to express a simple thank you for investing in a *COMMAND LIGHT* product. As a company, we are dedicated to producing the very best and most versatile flood lighting package available. We take great pride in the quality of our work and hope that you will find many years of satisfaction from the use of this equipment.

Should you have any problems with your product please do not hesitate to contact us.



3842 Redman Drive Fort Collins, CO 80524

PHONE: 1-800-797-7974 FAX: 1-970-297-7099 WEB: www.CommandLight.com



# **WARNING** Read this manual before installing or operating the *COMMAND LIGHT KNIGHT*<sup>2</sup>. Save this guide for future reference.

## Contents

Warranty	5
Warranty/Service	6
Breakage or Damage During Shipment	6
Product Safety Precautions	7
General Description and Specifications	8
Operation	9
Raising the light from the nested position	9
Returning the light to the nested position	10
Installation	11
Installation Kit	11
Tools Required	11
Installation Notes	11
Location Requirements	12
Mounting	13
Holster Mounting	13
Electrical Wiring	
120/240 VAC, 220 (Euro) VAC	14
Holster Wiring	14
Warning Device Installation	15
Maintenance	16
Cleaning	
Center Switch Adjustment	5-17
Rotation Belt Adjustment	
Power Failure	18
Rotate to center	18
Retract the upper stage.	18
Retract the lower stage	18
Without tools	
Troubleshooting	
Holster Circuit Board Error Codes	21
Technical Specifications – Standard AC Models (408A)	
Specifications	
Parts Lists - Exploded Views	
Exploded View (Base)	
Exploded View (Midplate)	
Exploded View (Lamp Tree)	
Exploded View (Backlight)	
Relay Box	
Wiring Schematics	
Relay Box	
Holster Box	
Dual Controls (VMUX/Wireless Systems)	
Lamp Tree	40



Command Light 3842 Redman Drive Fort Collins, CO 80524 PHONE: FAX: WEB: 1-800-797-7974 1-970-297-7099 www.CommandLight.com

# COMMAND LIGHT 5 YEAR LIMITED WARRANTY

*COMMAND LIGHT* products\* come with an industry leading 5-year warranty against any defects in materials and workmanship when used and operated for a period of five years. The responsibility of *COMMAND LIGHT* under this limited warranty is limited to the repair and replacement of parts found to be defective by *COMMAND LIGHT*.

Any parts damaged in shipping or by improper installation, overloading, abuse, or accident of any type or cause are not covered by this warranty. If equipment has been damaged in transit, a claim should be made against the carrier within three days, as we assume no responsibility for such damage.

If during this time period, you have any malfunctions not related to misuse, accident, neglect, or normal wear and tear, please take the following steps in order to have your light tower serviced under the *COMMAND LIGHT* warranty.

1. Contact us immediately for initial diagnosis at **info@commandlight.com** or **800-797-7974**; or if parts are needed contact **parts@commandlight.com**.

2. You will need to have immediate access to the light tower and the serial number. This process can be done by individuals with little mechanical ability. (Involves pushing buttons and telling us what the light tower is doing or not doing)

3. We then send parts (if needed) and have an authorized technician dispatched (if needed) with a written work authorization number and a base number of hours allotted to do repair. Hourly rates for service are to be determined at the time of authorization by *COMMAND LIGHT*, travel time is paid at a maximum of 50% of the authorized service rate.

4. We remain available for service support via phone, email, or video conference while the technician completes the repair, also to extend the original time allotted if additional issues arise. Immediate support cannot be guaranteed unless a time is scheduled prior to service.

5. Let us know when the repair is completed and reference the work authorization number. Email an invoice to info@commandlight.com or parts@commandlight.com. If you are unable to create an invoice email us for instructions for payment. Make sure any parts we have requested to be returned have been shipped back to the provided shipping address. If a return label is issued it must be used.

6. Finally, we will pay by mailing a check or crediting the account of the person, department, or company doing the repair. Payments will not be made until all requested parts have been returned.

Please contact us as soon as problems arise in order to execute our warranty. We must have knowledge of the issue and provide a work authorization in order to pay or reimburse labor or travel time.

Any unauthorized service voids this warranty. No work is authorized until written consent is provided by *COMMAND LIGHT*.

Contact Us Early — before any work is done — We'd love to help!

\*Excludes light producing components (bulbs, lasers, LEDs) These components may come with their own manufacturer warranty. Contact us and we can help get it.

# **Breakage or Damage During Shipment**

The transportation company is fully responsible for all shipping damage and will resolve problems promptly if you handle it correctly. Please read these instructions carefully.

Examine the contents of all shipping cases. If you find any damage, call your transportation agent at once and have them make a description on the freight or express bill describing the damage and the number of pieces. Then contact us and we will send you the original bill of lading. Also promptly contact the transportation company and follow their procedure for filing a claim. Each company will have a unique procedure to follow.

Please note, we cannot and will not enter claims for damages. If we filed a claim here, it would be sent to your local freight agent for verification and investigation. This time can be saved by you filing the claim directly. Every consignee is on the ground floor, in contact with the local agent who inspects the damaged goods, and thus, each claim can be given individual attention.

Since our goods are packed to comply with the regulations of all railroad, truck, and express companies, we cannot allow deduction from any invoice because of any damage, however, be sure to file your claim promptly. Our goods are sold F.O.B. factory. We take receipt from the transportation company certifying that the goods were delivered to them in good order and our responsibility ceases.

It is seldom that any breakage or damage occurs in any of our shipments and in no case will the customer be out any expense if they follow the above instructions.

Be sure to keep all damaged goods subject to examination of the truck or express company inspector, who may call on you sometime later. These damaged goods, of course, will belong to them, and they will inform you what to do with them. If you dispose of these damaged goods, your claim may not be paid.


# **WARNING**

# **Product Safety Precautions**

- Never operate the COMMAND LIGHT KNIGHT<sup>2</sup> near overhead high voltage power lines. The COMMAND LIGHT KNIGHT<sup>2</sup> is manufactured from electrically conductive materials.
- O not use the COMMAND LIGHT KNIGHT<sup>2</sup> for uses other than its intended purpose.
- O not move emergency vehicle with the light extended. Visually verify that the light is completely nested before moving vehicle.



- Do not change light position while people are located within its operating envelope. There are numerous pinch points that can cause serious bodily injury.
- ◎ Do not use a high-pressure washer or subject the light to high volumes of water when cleaning.
- Never use the *COMMAND LIGHT KNIGHT*<sup>2</sup> as a lifting device or mobile arm.
- Do not use a *COMMAND LIGHT KNIGHT*<sup>2</sup> that has been damaged or is not fully functional, including non-working indicator lamps.
- Never hold any part of the *COMMAND LIGHT KNIGHT*<sup>2</sup> with a hand or foot while it is in motion.
- S The *COMMAND LIGHT KNIGHT*<sup>2</sup> has numerous pinch points. Keep loose clothing, hands and feet clear of moving parts.



# **General Description and Specifications**

The *KNIGHT*<sup>2</sup> is designed to provide high intensity emergency scene lighting with quick precision. As with any electromechanical device, take precautionary steps to ensure safe operation.


**MWARNING** Never operate the *KNIGHT*<sup>2</sup> near overhead power lines.

There are several standard lighting options available for the *KNIGHT*<sup>2</sup>.

Model #	Description	Minimum Power Requirements
KL408A	6 x LED	1 kW Generator, 110 or 240 VAC

The emergency vehicle provides power for the 12 VDC elevated warning device circuitry. The umbilical corded control unit is powered via 12 VDC eliminating hazardous voltage levels within the hand held control box.

The *KNIGHT*<sup>2</sup> is manufactured to provide years of service with a minimum of maintenance.



# Operation


## Raising the light from the nested position

Using the control box, raise the lower or upper stage. You may also activate both stages simultaneously. Control switches are of momentary action style and must be held in the "on" position to actuate the stages.

The  $KNIGHT^2$  has an override system that precludes rotation of the upper stage until the lower stage has elevated approximately 16" from the nested position. When the lower stage is below 16" the following conditions exist:

- Upper stage is prevented from rotating.
- All lights are turned off, including strobe light if equipped, regardless of light switch positions.
- Prevents the upper stage from moving down if upper stage is not centered.

If the supply from the generator is marginal, position the *KNIGHT*<sup>2</sup> before turning on lights.



## Returning the light to the nested position

The *KNIGHT*<sup>2</sup> is equipped with an Autopark function as a standard feature. The "P" button on the control box initiates the Autopark sequence. Once initiated, the "Emergency Stop" button indicator is illuminated. Pressing the "Emergency Stop" button will cancel the Autopark sequence.

## **Autopark Sequence**

Press green button on the controller once. It does not need to be held in position. The Autopark sequence begins:

- 1. "Emergency Stop" **(** light is illuminated.
- 2. Lamps are extinguished.
- 3. Upper stage begins rotation to the center position. If equipped with back light option, back light begins oscillation and returns to the home position.
- 4. Once upper stage is centered, rotation stops, lower stage begins retracting.
- 5. After lower stage has fully retracted, upper stage begins retracting. Upon upper stage retracting fully, "Emergency Stop" () light turns off.

## Installation **ACAUTION**

The *KNIGHT*<sup>2</sup> must be installed by a designated installation facility by qualified personnel only. All safety precautions must be thoroughly understood before installation. Please consult the factory for additional installation information assistance.

#### Installation Kit

Included with the *KNIGHT*<sup>2</sup> is an installation kit. Verify that the kit contains the following items:

<ol> <li>(1) 50 feet of 2GA-2 Conductor power cable</li> <li>(1) Pre-wired HOLSTER BOX w/cover</li> </ol>	<ul><li>(1) 50 feet of 22GA-20 conductor cable</li><li>(1) Handheld Controller</li></ul>
(1) Small hardware parts bag with:	
(4) mounting spacers	(4) 5/16-18 x 2 <sup>1</sup> / <sub>2</sub> " bolts
(4) 5/16-18" nylon lock nuts	(8) 5/16" flat washers
(4) large diameter flat washers	(2) <sup>1</sup> / <sub>4</sub> -20 x 5/8" Phillips pan head machine screws
(4) $\frac{1}{4}$ flat washers	(2) $\frac{1}{4}$ -20" nylon lock nuts
(3) $\frac{1}{2}$ 90° sealing connector w/nut	(1) 1" 90° sealing connector w/ nut

## **Tools Required**

Lifting device (crane, forklift, block and tackle, etc.) Sling for lifting Drill <sup>21</sup>/<sub>64</sub>", <sup>17</sup>/<sub>64</sub>" drill bits Hole punch for metal with <sup>7</sup>/<sub>8</sub>" and <sup>15</sup>/<sub>16</sub>" diameter capacity Phillips head screwdriver, #2 Command Light flat blade screwdriver (included with light) <sup>7</sup>/<sub>16</sub>" and <sup>1</sup>/<sub>2</sub>" combination wrenches and/or ratchet and <sup>7</sup>/<sub>16</sub>" and <sup>1</sup>/<sub>2</sub>" sockets 8" adjustable wrench Tongue and Groove Pliers Wire stripper or razor blade knife Solder-less wire connector crimp tool Silicone based gasket sealer, RTV<sup>TM</sup> recommended

#### Installation Notes

**CAUTION** The *KNIGHT*<sup>2</sup> weighs approximately 165 pounds. Use mechanical assistance to lift the light into installation position such as a forklift or crane.


Use the provided fender washers under the mounting surface to distribute the weight load evenly.

When routing the connecting electrical wires take care to avoid sharp bends, hot components or other hazards to the wire.

The *KNIGHT*<sup>2</sup> is not designed to be operated in a raised position while the vehicle is in motion. The *KNIGHT*<sup>2</sup> includes warning circuit wiring to enable a warning device.

## Location Requirements

The standard *KNIGHT<sup>2</sup> KL408* models can be mounted on any location that is 47" x 25", additionally allow for a minimum of 3" of space around the perimeter of the nested tower. The surface should be flat or have only a slight crown. For a recessed installation, allow for a minimum of 3" of space around the perimeter of the tower taking into consideration the dimensions of the tower both fully nested and fully elevated. Consult with factory before construction of recessed installation. Verify all dimensions before installation to ensure proper operation of light will not infringe on other installed components. For all other installations refer to the dimensional drawing on page 24 of this guide that represents your particular model of light. The drawings reflect the dimensions of the "working envelope" of a typical light tower. Make certain sufficient clearances are incorporated in your installation to allow for variations (vehicle body flex, environmental conditions, future servicing needs, etc.) If your light model is not represented, call or email the factory prior to beginning any construction of a recessed installation.



Four mounting bolt holes are required. Additional holes may be drilled in the frame ends if necessary to clear obstructions.

Access holes for the power cord cabling should be in close proximity to the relay box access holes on the light. Installing the cords with a sweeping 90° or 180° bend will provide better results.


The control box holster should be mounted in an area shielded from the weather. Allow a minimum of 10" clearance above the control box holster mounting location for easy access to the controller.

#### Mounting

Place the provided spacers in the location of the light mounting holes. The spacers may be modified to conform to the contour of the mounting location.

Remove any obstructions below the mounting surface such as headliners.

Attach any necessary lifting attachments to the *KNIGHT*<sup>2</sup>. The center of gravity (balance point) is slightly behind the lower bank of lights.



**CAUTION** Slowly lift the *KNIGHT*<sup>2</sup> and check for balanced lifting. Lower and make any necessary adjustments to the lift points.

Lift and place the  $KNIGHT^2$  into position above the spacers. Before placing the full weight of the unit on the spacers align spacers with the holes in the end frame castings.

Drill <sup>21</sup>/<sub>64</sub>" holes in the mounting surface using the end casting holes as a template.

Fasten the light using the provided hardware. To ensure a weather-tight installation apply a thin bead of silicone based gasket sealer to the base of the spacer and underside of bolt head.

Remove any lifting straps and devices from the *KNIGHT*<sup>2</sup>.


Locate and drill the wire feed holes.

#### Holster Mounting

Using the holster mount as a template, mark hole locations.

Drill <sup>17</sup>/<sub>64</sub>" mounting holes.

Drill any holes required to route the control cable from the holster to the *KNIGHT*<sup>2</sup> relay box. Attach the holster to the holster mount with the provided hardware.



## **Electrical Wiring**


Please Note: Detailed internal wiring schematics are located at the back of this user guide.


Run the control wire from the control box holster to the *KNIGHT*<sup>2</sup>.

Run the power wire from the breaker box or generator to the *KNIGHT*<sup>2</sup>. A 20 Amp breaker is recommended on AC models with LED fixtures.

Make the control connections in the *KNIGHT*<sup>2</sup> relay box.

The standard model KL408A series *KNIGHT*<sup>2</sup> comes pre-wired to connect to 120 VAC. It is necessary to remove the jumper connecting the red and black terminals for 240 VAC operation.






If 240 VAC operation is desired, remove the jumper wire between the red and black leads.

## 220 VAC European

If the light tower is ordered with 220 VAC (Single Hot Leg) wiring, only use a single hot conductor from the power source, the other is not needed.



## Holster Wiring

Determine if an elevated warning device will be used in conjunction with the light tower. If a warning device will be used, use the wiring diagram on the next page, otherwise, use the wiring diagrams on pages 37-38 back of the user guide.

After routing the control cable into the holster through the sealing connector, attach individual wires to the provided connectors and insert the connectors into the proper ports on the circuit board.

## Warning Device Installation


Tools Required:

- <sup>3</sup>/<sub>32</sub>" Flathead Screwdriver
- Wire Strippers
- Small Torch or Lighter



Make sure Truck 12V power is OFF until wiring is complete at the holster circuit board and the light tower. Incorrect wiring or live wires during install can cause damage to circuitry.

Wire the gray 22-20 control cable wires to the small connectors using the wiring schematics provided on pages 41 and 42. There are 2 different schematics, one is the standard version and the other is the version for dual control with wireless controllers or V-Mux control. The standard schematic will be used for V-Mux or any other multiplex system if it is only being used for elevated warning. A V-Mux wiring schematic and circuit board troubleshooting guide are included.



**Detaching & Attaching the Controller** 



Make sure the tab on the coil cord connector lines up with the slot on the controller connector. Rotate the coil cord connector clockwise until finger tight. **DO NOT** use tools to tighten this connector.

# Maintenance

## Cleaning

The *KNIGHT*<sup>2</sup> is constructed with corrosion resistant aluminum and stainless steel fasteners. To further enhance corrosion resistance all exposed surfaces receive a powder coated paint finish. To ensure years of trouble free service periodically clean all external surfaces with a mild detergent solution and a gentle spray of water. **DO NOT USE A HIGH-PRESSURE WASHER**, which will force water into sensitive electric circuitry.

Lamp lenses may be cleaned with any commercially available glass cleaner.

Upper and lower stage actuators are sealed units and do not require adjustment or lubrication. The actuators have slip-clutches to compensate for minor stroke tolerances at the limits of its travel. The actuator may produce a ratcheting sound at each end of the stroke which is normal. The actuators should not be made to ratchet excessively, this can lead to premature actuator clutch failure.

All pivot points on the *KNIGHT*<sup>2</sup> are self-lubricating thermal polymer. Periodic cleaning with a moisture displacing cleaner and soft bristle brush, without disassembly, to remove accumulated dirt and debris will minimize wear.

## Center Switch Adjustment

## WATCH THE VIDEO AT <u>WWW.COMMANDLIGHT.COM/TECHNICAL-VIDEOS/</u> Caution: For best results, angle of vehicle should be less than 10 degrees.

- 1. Raise lower section high enough to comfortably work on, and above the set safety limit (i.e. Lights will turn on), then raise lamp tree to a 45 degree angle.
- 2. Visually verify the centering cam on the rotation spindle is contacting the roller of the center switch arm.
- 3. Ensure that when the point of the centering cam is aligned with the roller of the center switch arm, there is some play in the center switch arm. Without this play, the switch could be crushed or damaged during rotation.
- 4. Rotate off center, then press the auto park button and let light tower proceed through sequence until the lamp tree is a couple inches above the nested position, hit emergency stop.
- 5. Visually determine which side the lamp tree will be hitting the lift arm, then lower lamp tree completely using the motion switch on the handheld controller.
- 6. Raise lower section above safety limit and to comfortable working height.
- 7. Make reference marks with a permanent marker on both sides of the cam.
- 8. Loosen screw on center switch cam slightly.
- 9. Tap centering cam toward the side that the lamp tree is hitting the lift arm.
- 10. Fully tighten the screw holding the center switch cam.
- 11. Raise lamp tree to a 45 degree angle, rotate off center.
- 12. Repeat steps 4-9 until satisfied with centering of the lamp tree.
- 13. If it looks like center is now adjusted properly, raise lamp tree to a 45 degree angle, and lower stage all the way up, press autopark and let it go through the entire sequence.
- 14. If it is still hitting off center, repeat previous steps.
- 15. If problems adjusting center still persist you may need to adjust the center switch bracket, or call Command Light at 1-800-797-7974 for further assistance.

## Notes:

• Making a mark next to the cam on the bottom of the spindle will make judging the adjustments much easier.






- With the centering cam slightly loose, it may be easier to adjust its position by tapping on its edge with the assistance of a socket driver rather than attempting to move by hand.
- Having the lamp tree at either extreme of fully up or down, will affect the degree of centering. Setting center while the lamp tree at a 45 degree angle produces the best results.

If problems persist, please call Command Light at 1-800-797-7974.

## Rotation Belt Adjustment / Tightening WATCH THE VIDEO AT <u>WWW.COMMANDLIGHT.COM/TECHNICAL-VIDEOS/</u>

- 1. Raise lamp tree 45° and rotate away from motor to access rotation motor screws.
- 2. Remove the (4) screws from the front midplate cover.
- 3. Loosen, but do not remove, screws that retain rotation motor.
- 4. Using a 1/2" wrench, loosen the jam nut on the belt tensioner bolt. Using a 3/16" Allen socket tighten the tensioner bolt to 20 inch pounds. Tighten the jam nut to lock bolt in place. Use caution to not over tighten drive belt. Rotate lamp tree 180 degrees to verify that belt is not too tight. If belt is too tight, rotation motor noise level will rise noticeably.
- 5. Replace the cover before returning light tower to active service.



## **Power Failure**

The *KNIGHT*<sup>2</sup> can be retracted manually if power to the unit is lost. If power loss is temporary, reestablishing power may be easier than manually retracting the light.

Note: Disconnect power source from the *KNIGHT*<sup>2</sup> before manual operation.

## WATCH THE VIDEO AT WWW.COMMANDLIGHT.COM/TECHNICAL-VIDEOS/

## Retract the Upper stage

Locate the black, plastic literature canister mounted to the side of the base of the tower, it contains a 90-degree 3/16 allen wrench and a 3/8th drive  $\frac{1}{4}$ " allen socket.

Use the 90-degree allen wrench to remove the outer cover screw on the upper actuator.

Insert the <sup>1</sup>/<sub>4</sub>" socket into drive socket in the actuator gear box and rotate clockwise to retract the ram until lamp tree is fully lowered.

Replace the cover screw! The actuator may become damaged if the cover screw is not replaced.



#### KL SERIES: MANUAL LIGHT TOWER LOWERING

In the event your tower loses power or your controller breaks, this Technical Video shows responders how to manually lower the KL Series light tower so that both crew and truck can return to the fire department for further diagnosis.

## Rotate to Center

Slowly apply pressure to the lamp tree to manually rotate to the centered position. Trying to rotate too quickly or with too much pressure can break the rotation motor shaft. Be certain that you rotate in the proper direction; the upper stage can rotate a full 360°. Generally, you need to rotate the lamp tree in the direction that requires the least amount of travel in order to reach a centered position.

If manual rotation causes the rotation belt to slip, this is alright if minimized. Excessive slippage on the belt may cause enough damage for the need of belt replacement.

## Retract the Lower Stage

Using the same allen tools as before, remove the cover screw and retract the ram of the actuator as far as possible for safe travel back to station or repair facility.



Be careful not to hit the lower lamps on main electrical box if your tower has the Backlight option and the lamps are not flush with the fixed lamps.

If needed the Backlight may be rotated back to the home position where it is flush with the fixed lamps. Slowly apply pressure to the Backlight lamps to manually rotate to the home position. Trying to rotate too quickly or with too much pressure can break the Backlight motor shaft.

Replace the cover screw on the actuator!

## IN THE EVENT THAT ALLEN WRENCHES FOR LOWERING THE TOWER CANNOT BE FOUND THE TOWER MUST BE LOWERED BY REMOVING THE ACTUATOR MOUNT PINS:

#### Rotate to center without the lowering tools

Slowly apply pressure to the rotation platform to manually rotate to the centered position. Trying to rotate the platform too quickly or with too much pressure can break the rotation motor shaft or cause the toothed drive belt to shear a tooth. The upper stage can be rotated in either direction.


Generally, you need to rotate the platform in the direction that requires the least amount of travel in order to center the platform.

#### Retract the lower stage without the lowering tools

Support the Midplate (rotation) assembly with temporary blocking to relieve the tension on the lower actuator pivot pins.

Using a small flat blade screwdriver or needle-nose pliers, remove the retaining rings that secure the lower pivot pin in place.

Use a brass drift punch to remove the pivot pin from the extension end of the actuator. Avoid using a hardened steel punch which could peen the end of the shaft thus damaging the bore within the aluminum pivot blocks.



**ACAUTION** The light weighs in excess of 100 pounds, use

caution. Apply upward pressure on the main lift arm to remove support blocking then slowly lower the lift arm allowing the actuator shaft to extend past the lower pivot blocks.

#### Retract the upper stage without the lowering tools


Support the lamp tree with temporary blocking to relieve the tension on the upper actuator pivot pins. Using a small flat blade screwdriver or needle-nose pliers, remove the 4 e-clips securing the lower pin of the upper actuator.

Support the lamp tree. Depending on configuration, the weight of the lamp tree may exceed 50 lbs. Use a brass drift punch to remove the pin.

Lift up on lamp tree to remove support blocking. Rotate the actuator towards the front of the light. The upper stage will not be completely lowered but should provide ample clearance to transport the light.

Cushion and secure the actuators and other components as necessary before transporting.

New retaining rings must be installed before returning light to service.



# Troubleshooting

Problem	Possible Cause	Solution
Unit will not extend	No power to the unit	Check power input connections.
	Incorrect installation	Refer to installation instructions.
Upper stage will not rotate	Lower stage not raised above	Raise lower stage higher.
	safety limit (16" above base)	
	Rotation motor failure.	Consult with factory.
Lights will not illuminate.	Lower stage not raised above	Raise lower stage higher.
	safety limit (16" above base)	
	Circuit breaker tripped.	Check circuit breaker at power
		supply.
	Lamp filament broken.	Replace lamp.
Rotation coasts after switch is	Rotation belt is loose.	Adjust belt to provide no more
released		than <sup>1</sup> / <sub>4</sub> " slack
Unit will not nest	Upper stage not centered.	Raise lower stage higher than
		16". Center upper stage (green
		light illuminated)
	Unit being operated on a slope	Lower lamp tree to horizontal.
	>5°.	Using a pike pole, hold unit level
		while lowering to nest position.
Autopark button must be held in	Faulty or stuck nest switch.	Check nest switch ground and
to park unit		operation. Rubber boot may have
		shrunk and is holding in switch.
	Water in electronics.	Remove moisture from ground
		points and electronics. Do not
		use a pressure washer to clean
		unit.
Upper Actuator & Rotation start	Down limit switch stuck or	Aluminum plunger which acti-
at the same time	damaged.	vates down limit switch should
		move freely. Verify proper switch
		operation.
Wires on back light catching	Check for 90 degree sealing con-	Contact factory for replacement
	nector on lamp tree.	part.
No lights or rotation	Check safety limit sensor, bad,	Contact factory for replacement
	etc.	part.
Autopark is off Center	Center switch out of	Refer to instructions on pages
	alignment.	17 and 18.
Popping noise during Back	Switch boots stuck, faulty rota-	Replace switch boots. Contact
Light Rotation	tion relay.	factory for replacements parts.



PWR AND ERROR LED GUIDE BOARD REV 5. MAIN BOARD 5.3, FIRMWARE 4

ON OFF	READY TO GO
PWR ERROR OFF OFF	NO POWER AND/OR NO GROUND AT EITHER CBAT OR VBAT TERMINALS CHECK VBAT, CBAT, AND GND TERMINALS. SHOULD HAVE 12-18 VDC CHECK 2 AMP FUSE AT MAIN BOARD
PWR ERROR FLASH 1X PAUSE FLASH 2X PAUSE, REPEAT	ERROR CODE 12 NO CBAT POWER AT 3 PIN GRAY CONNECTOR "CBAT" TERMINAL, COMMAND LIGHT IS NOT POWERED. CHECK FOR 12VOLTS AT GRAY 3 PIN CONNECTOR, TERMINAL CBAT.
PWR ERROR FLASH 1X PAUSE FLASH 3X PAUSE, REPEAT	ERROR CODE 13 COMMUNICATION ERROR BETWEEN MAIN BOARD AND KEYPAD BOARD. CHECK ALL CAT 5 CONNECTIONS BETWEEN THE MAIN BOARD AND THE KEYPAD BOARD INCLUDING COIL CABLE.
PWR ERROR FLASH 1X PAUSE ON PAUSE	ERROR CODE 14: WILL ONLY ERROR ON FIRST LOGIN ATTEMPT AND DOES NOT REPEAT. YOU MUST LOOK FOR THIS ERROR CODE AS YOU ARE TRYING TO LOGIN TO THE DEVICE. INDICATES THAT COMMAND LIGHT CONTROLLER DOES NOT HAVE CONTROL OF THE SYSTEM. - IF USING VMUX - CHECK GREEN 5 PIN CONNECTOR "VMUX IF" FOR 12 VOLT POWER AT THE "CTRL" TERMINAL. IF NO, CHECK VMUX DUAL CONTROL BOARD. IF NOT USING VMUX, ENSURE BLACK/WHITE WIRE IS TERMINATED INTO THE CTRL TERMINAL AND THAT THIS TERMINAL HAS 12VDC.

# Technical Specifications – Standard AC Models (408A)

		Height(Dep	th) L	ength	Width
Re	etracted	12"	4	7"	23"
Ex	tended	88"	5	2"	23"
Re	ecessed installation	14"	5	8"	30" Minimum
Weight:	165 pounds				
Wiring:					
	Main Power VAC	10/4 SO cord		50' provid	ed
	Control wiring	22/20 PVC Jac	eketed	50' provid	ed
Relay prote	ection:				
	Lights	Cole-Hersey	3055	100 amps	
	Other electrical	Cole-Hersey	3055	40 amp	

**Dimensions** (with strobe and <sup>1</sup>/<sub>2</sub>" mounting spacers) – May vary by model:

#### **Current Draw / Power Requirements:**

	Average	<b>Generator Requirement</b>
75 Watt LED	120 VAC/4 amps	1 kW minimum


Lift actuators and rotation motor will cause higher current draw during use.

#### **Motor Duty Cycle:**

(All motors the	ermally protected, specifications are to thermal relay trip):
Lower stage	1:3 (90 seconds maximum per 5 minute)
Upper stage	1:3 (90 seconds maximum per 5 minute)
Rotation	5-6 Revolutions

#### **Motor Speed:**

Lower stage Upper stage Rotation	<ul><li>1.0 inches per minute</li><li>0.5 inches per minute</li><li>2.75 RPM at lamp tree</li></ul>	<ul><li>12 seconds to full extension</li><li>12 seconds to full extension</li></ul>
Operation:	Angle of vehicle	10° maximum incline
Wind load:	Design maximum Maximum tested	60 mph 90 mph




# EXPLODED VIEWS AND WIRING SCHEMATICS

# Parts List - (Base)


TEM	QTY	PART NUMBER	DESCRIPTION
1	1	075-01000A	FRAME, COMPLETE, WELDMENT, KNIGHT2
2	4	034-13033	SCREW,HH,1/4-20x7/8,SS
3	2	034-11112	Nut,HEX,FULL,1/4-20UNC,SS
4	10	034-11042	SCREW,HH,5/16-18x1,SS
5	2	075-01600	BLOCK, PIVOT, LOWER ACTUATOR, KNIGHT2
6	1	075-01700W	ARM, STABILIZER, WELDMENT, KNIGHT2
7		075-06010	PIN,STABALIZER,LOWER
8	6	069-15336	E-Ring, 5133-50, .044T, SS
9	1	075-06050	PIN,LOWER ACTUATOR, UPPER LIFT ARM
10	1	075-06080	PIN,LOWER ACTUATOR,KNIGHT 2
11		075-02000WRDC	ARM,LIFT,KNIGHT,2GEN DC
12	1	075-06040	PIN, MAIN LIFT, LOWER, KNIGHT2
13	2	075-01300	CAP, MAIN LIFT PIN
14		034-11053	WASHER,LOCK,SPRING,REGULAR, 5/16", SS
15		075-07300	COVER,RELAY BOX,KL4XX
16		034-11057	NUT,NYLOCK, 5/16-18 UNC,SS
17		034-10961	SCREW,PHP,10-24 UNCx0.375
18		075-06500	PLATE, PLUNGER STRIKE, KNIGHT2
19		065-12861	CLAMP,LOOM,#8,SS
20		034-11001	SCREW,PHP,1/4-20 UNCx0.5
21	4	034-11028	WASHER,LOCK,SPRING,REGULAR, 1/4", SS
22	1	034-13668	SCREW, FHPMS, 1/4-20 UNC x 7/8 in, SS
23		034-11116	NUT,NYLOCK,THIN, 1/4-20 UNC,SS
24	2	034-11033	NUT,NYLOCK, 1/4-20 UNC,SS
25	1	065-15001	CANISTER, DOCUMENT, BLACK
26		065-13846	BUSHING, .5 X .75 X .03125
27		065-13845	BUSHING5 X.375 X .03125
28	1	065-13851	PLUG, RELAYBOX, KNIGHTLIGHT
29	1	075-07203	WELDMENT, BOX, RELAY, BASE, KL4XX
30	1	069-15384	ACTUATOR,6",12 VOLT,KL LOWER,BEAR
31	1	065-14784	LOOK UP LIGHT, 4 RD, 48 IN CABLE, FRC, CL

# Exploded View - (Base)




# Parts List - (Mid-Plate)

ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	065-13013	FEET, RUBBER, RECTANGULAR, CL
2	4	034-10951	NUT,NYLOCK, 8-32 UNC,SS
3	4	065-13847	BUSHING, .500 X .500 X .0625
4	1	075-03531	STOP, MIDPLATE, EXTENDED, KL2
5	1	075-03600	COVER, REAR, MIDPLATE, SURROUND
6	1	075-03605	COVER, FRONT, SURROUND, KV2
7	1	075-03610	SURROUND, MIDPLATE, KV2
8	1	075-03200A	ASSEMBLED, MIDPLATE, KNIGHT2
9	1	075-06060	Pin, Tree Mount, Knight2
10	1	075-06070	PIN, UPPER ACTUATOR, LOWER, KL4XX
11	2	075-25000	Arm, Mount, Tree, Knight2
12	10	069-15336	E-Ring, 5133-50, .044T, SS
13	2	034-11028	WASHER,LOCK,SPRING,REGULAR, 1/4", SS
14	10	034-10961	SCREW,PHP,10-24 UNCx0.375
15	2	034-11002	SCREW,PHP,1/4-20 UNCx0.625
16	1	069-15383	ACTUATOR, UPPER, KL
17	1	075-06021	PIN,STABILIZER, REINFORCED,UPPER,KV2
18	4	034-10941	SCREW,PHP,8-32 UNCx0.75
19	2	075-06112	GUIDE,WIRE,SHORT,KL4XX



# Parts List - (Lamp Tree)


ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	075-05400	Plate, Nest, Tree, Knight2
2	6	075-08031	MOUNT, LAMP, PSP1, KL/SL4XX
3	4	065-14001	FIXTURE,LED,75W,120VAC,8 DEGREE,BLACK,CL
4	1	065-12867	STROBE, PRE-WIRED, INDICATE COLOR
5	1	069-15352	CONXALL, MINICON, 2 PIN, PANEL
6	2	STD HARDWARE-FHMS-131	SCREW,FHPMS,1/4-20 UNC x 7/8 in,SS
7	2	STD HARDWARE55	SCREW,PHP,10-24 UNCx0.375
8	18	STD HARDWARE-FHMS-83	SCREW,FHPMS,10-24 UNC x 1/2 in,SS
9	6	STD HARDWARE-HHCS-04	SCREW,HH,1/4-20x3/4,SS
10	2	STD HARDWARE-HHCS-03	SCREW,HH,1/4-20x5/8,SS
11	12	STD HARDWARE LW35	WASHER,LOCK,SPRING,REGULAR, 1/4", SS
12	6	065-13843	GROMMET,5/16 ID,1 OD,BLK
13	1	075-05301HW	TREE,LAMP,WELDMENT,STD,KL4XX,HW
14	1	065-10069	BLOCK, TERMINAL, DIN, DN-T10-BLACK
15	1	065-10068	BLOCK, TERMINAL, DIN, DN-T10-BLUE
16	1	065-10072	BLOCK, TERMINAL, DIN, DN-T10-RED
17	1	065-10067	BLOCK, TERMINAL, DIN, DN-T10-GRAY
18	1	065-10073	BLOCK, TERMINAL, DIN, DN-T10-WHITE
19	1	065-10074	BLOCK, TERMINAL, DIN, DN-T10-YELLOW
20	2	065-10070	BLOCK, TERMINAL, DIN, DN-T10-GREEN
21	2	065-10075	BRACKET,END,DIN,DN-EB35
22	2	065-10075	BRACKET, END, DIN, DN-EB35
23	1	DN-T10-BLUE_WHITE	BLOCK, TERMINAL, DIN, DN-T10-BLUE
24	1	DN-T10-GREEN_BLACK	BLOCK, TERMINAL, DIN, DN-T10-GREEN
25	1	DN-T10-GREEN_WHITE	BLOCK, TERMINAL, DIN, DN-T10-GREEN
26	1	065-10071	BLOCK, TERMINAL, DIN, DN-T10-ORANGE
27	1	065-10070	BLOCK, TERMINAL, DIN, DN-T10-GREEN
28	1	DN-T10-YELLOW_BLACK	BLOCK, TERMINAL, DIN, DN-T10-YELLOW
29	2	065-13999	FIXTURE,LED,75W,12VDC,2 DEGREE,BLK,CLITE
30	4	STD HARDWARE-HHCS-02	SCREW,HH,1/4-20x1/2,SS





# Parts List - (Backlight)


ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	075-05603	Block, Bearing, Backlight, Knight2
2	1	075-05604	STRIKER, ROTATION, BACKLIGHT, KL4XX
3	1	075-05504	Shaft, Main, Backlight, Knight2
4	2	065-12935	BOOT, PUSHBUTTON, BLK, BACK LIGHTS
6	3	065-13840	WASHER, 1/2 HOLE, ID. 515, OD. 885, DELRIN, WHT
7	1	069-14161	BELT, BACK LIGHT, HEAVY DUTY, CL KL
8	1	065-12378	PULLEY,HTD,P5mm,W15mm,G17,DF,B8mm
9	4	034-11221	WASHER,LOCK,5/16,HI COLLAR,SS
10	3	075-08098	BUSHING, MOTOR, BL, KL4XX
11	1	075-05598	BRACKET, BACKLIGHT, REVISED, KLxxx
12	1	065-14187	RELAY SOCKET, 3A, 14 PIN, SRT BUILDS
13	1	075-05506	BACK LIGHT, DRIVE/ROTATION PULLEY, KL4XX
14	1	034-10975	SCREW,FHPMS,10-24 UNC x 3/4 in,SS
15	1	034-13033	SCREW,HH,1/4-20x7/8,SS
16	2	034-11001	SCREW,PHP,1/4-20 UNCx0.5
17	5	034-10961	SCREW,PHP,10-24 UNCx0.375
18	1	034-14901	SCREW,FHPMS,4-40 UNC x 3/4 in,SS
19	2	034-10979	WASHER,LOCK,SPRING,REGULAR, #10, SS
20	3	034-10981	NUT,NYLOCK, 10-24 UNC,SS
21	4	034-11157	SCREW,SHCS,5/16-18x3/4,SS
22	2	034-11182	SCREW,SH SET,M4x0.7 x 10mm,SS
23	1	034-13084	8-32 UNC x 3/8 SH Set Screw SS
24	1	034-13311	1/4-20 UNC x 1/4 SH Set Screw SS
25	2	069-15360	SWITCH, DOWN LIMIT / NEST / BL LIMIT
26	1	065-14186	RELAY, BL, AUTO PARK, CL, SRT, MY2KDC12
27	1	065-14185	GEAR MOTOR, BACKLIGHT, CL, KL
28	1	075-08111	GAURD, BACKLIGHT, SOCKET RELAY, KNIGHT 2
29	2	034-11029	WASHER, FLAT, SAE, 1/4", SS
30	1	034-13672	NUT,NYLOCK, 4-40 UNC,SS
31	2	065-13846	BUSHING, .5 X .75 X .03125
32	2	069-14205	WIRE GUIDE CLIP, NYLON,5/16, W2 KL BL
33	1	034-11112	NUT,MS,HEX2,1/4-20UNC,SS





Exploded View - (Backlight)


# Parts List - (Relay Box)

1	1	075-07203	WELDMENT, BOX, RELAY, BASE, KL4XX
2	1	065-12365	CLAMP,LOOM,#6,SS
3	1	065-12861	CLAMP,LOOM,#8,SS
4	1	9600K15	GROMMET, PUSH-IN, 0.2812 ID, 0.5625 OD, 0.0625 GROOVE
5	1	065-12935	BOOT, PUSHBUTTON, BLK, BACK LIGHTS
6	1	065-13851	PLUG,RELAYBOX,KNIGHTLIGHT
7	1	069-15360	SWITCH, DOWN LIMIT / NEST / BL LIMIT
8	1	075-07100	PLATE,RELAY MOUNT,KNIGHT V2
9	2	034-11002	SCREW,PHP,1/4-20 UNCx0.625
10	2	034-10110	WASHER,LOCK,18-8SS,INTERNAL,1/4in
11	3	034-10966	SCREW,PHP,10-24 UNCx0.75
12	9	034-10978	WASHER,LOCK,18-8SS,INTERNAL,#10
13	3	034-10981	NUT,NYLOCK, 10-24 UNC,SS
14	2	034-10968	SCREW,PHP,10-24 UNCx1
15	4	034-13100	NUT,MS,HEX2,10-24UNC,SS
16	4	034-10977	WASHER,FLAT,SAE, #10, SS
17	1	065-14577	POWER SUPPLY,ASSEMBLED,CL,KL
18	2	034-11028	WASHER,LOCK,SPRING,REGULAR, 1/4", SS
19	2	034-11112	NUT,MS,HEX2,1/4-20UNC,SS
20	1	065-12854	STRAIN RELIEF, DOMED, SCR .5171, 3/4 NPT, BLACK
21	1	065-12857	LOCKNUT,NYLON,3/4 NPT,BLACK
22	2	065-12852	STRAIN RELIEF, DOMED, SCR .2447, 1/2 NPT, BLACK
23	2	065-12856	LOCKNUT,NYLON,1/2 NPT,BLACK
24	1	065-12875	STRAIN RELIEF, DOMED, SCR .1631, 3/8 NPT, BLACK
25	2	065-12831	LOCKNUT,NYLON,3/8 NPT,BLACK
26	2	065-12890	STRIP, BARRIER, 20 POLE
27	6	034-13288	SCREW,PHP,4-40 UNCx0.75
28	6	034-14283	WASHER,LOCK,18-8SS,INTERNAL,#4
29	1	069-14322	TERMINAL BLOCK,5 POLE
30	2	034-10942	SCREW,PHP,8-32 UNCx1
31	4	034-11175	WASHER,LOCK,18-8SS,INTERNAL,#8
32	14	034-10951	NUT,NYLOCK, 8-32 UNC,SS
33	1	065-13529	BREAKER, 12V 20A, SINGLE POLE
34	10	034-10939	SCREW,PHP,8-32 UNCx0.5
35	1	065-12828	TERMINAL STRIP,16 POLE
36	3	065-14020	RELAY, DOUBLE POLE, 240VAC
37	2	034-10938	SCREW,PHP,8-32 UNCx0.375
38	20	065-13730	SOCKET, SINGLE POLE, RELAY
39	20	065-13738	RELAY, 12V, SINGLE POLE
40	5	034-10961	SCREW,PHP,10-24 UNCx0.375











12: COMMAND LIGHT DOES NOT HAVE POWER 13: COMMUNICATION ISSUE BETWEEN THE KEYPAD AND MAIN BOARD 14: DOES NOT HAVE CONTROL OF SYSTEM (VMUX ONLY)

FOR USE WITH ALL COMMAND LIGHT MODELS MAIN BOARD REV 5.3.3, DIAGRAM REV 4, FIRMWARE 4.0




FOR USE WITH ALL COMMAND LIGHT MODELS MAIN BOARD REV 5.3, DIAGRAM REV 3



WIRELESS

CONTROL SPLITTER BOARD



# LAMP TREE (STANDARD LAMPS)